

Ryhmä: 510


LM-42A MEAT MINCER

Code	Item name
LM42A001	LM-42A GRINDING HOUSE CAST IRON
LM42A001,1	LM-42A GRINDING HOUSE STAINLESS
LM42A002	LM-42A FEED SCREW (INCL.PART 6) STAINLESS
LM42A003	LM-42A ENTRY NUT
LM42A004	LM-42A KNIFE
LM42A005	LM-42A HOLEPLATE
LM42A006	LM-42A STUD
LM42A015	LM-42A BEARING TRESTLE
LM42A016	LM-42A PROTECTIVE PLATE
LM42A017	LM-42A LOCK NUT KM 10
LM42A019	LM-42A BEARING 3210
LM42A024	LM-42A DRIVE SHAFT
LM42A026	LM-42A BEARING 6210 2RS
LM42A027	LM-42A BUSHING
LM42A030	LM-42A MOTOR 7,5kW
LM42A035	LM-42A LID BOLT
LM42A036	LM-42A LID BOLT
LM42A038	LM-42A MIXER
LM42A039	LM-42A NYLON BEARING
LM42A040	LM-42A LOCK NUT
LM42A042	LM-42A SHAFT FOR MIXER
LM42A045	LM-42A COVER FOR MIXER SHAFT
LM42A046	LM-42A SPALSH COVER BRACKET
LM42A047	LM-42A SPALSH COVER
LM42A048	LM-42A FRONT PLATE
LM42A063	LM-42A CONNECTION BOX
LM42A069	LM-42A COVER FOR CONNECTION BOX
LM42A076	LM-42A HINGE SHAFT
LM42A079	LM-42A HINGE BEARING
LM42A080	LM-42A SPRING
LM42A082	LM-42A RUBBER
LM42A099	LM-42A LOCK NUT KM 15
LM42A100	LM-42A NYLON BEARING
LM42A102	LM-42A DRIVE SHAFT FOR MIXER
LM42A103	LM-42A PULLEY
LM42A104	LM-42A BELT XPZ-1060
LM42A105	LM-42A GEARBOX
LM42A107	LM-42A TURNBUCKLE
LM42A108	LM-42A PULLEY
LM42A113	LM-42A BACK COVER
LM42A126	LM-42A SAFETY SWITCH
LM42A136	LM-42A KEY
LM42A138	LM-42A GASKET AS 45x62x10
LM42A139	LM-42A KEY
LM42A140	LM-42A KEY
LM42A141	LM-42A KEY
LM42A143	LM-42A WHEEL WITH BRAKE
LM42A144	LM-42A WHEEL
LM42A145	LM-42A GASKET AS 35x52x10
LM42A146	LM-42A GASKET A 53x68x10
LM42A147	LM-42A FLANGE
LM42A148	LM-42A MOTOR FOR MIXER 1,1 kW
LM42A149	LM-42A KEY
LM42A150	LM-42A COVER
LM42A151	LM-42A EMERGENCY STOP BUTTON
LM42A152	LM-42A PROTECTIVE RUBBER
LM42A153	LM-42A START BUTTON
LM42A154	LM-42A STOP BUTTON
LM42A158	LM-42A RAIL
LM42A159	LM-42A CONTACTOR DILM 17-10 24V

Ryhmä: 510


LM-42A MEAT MINCER

<b>Code</b>	<b>Item name</b>
LM42A159,1	LM-42A CONTACTOR (MIXER) DILM 9-10 2
LM42A160	LM-42A THERMAL OVERLOAD RELAY ZB 32-24
LM42A160,1	LM-42A THERMAL OVERLOAD RELAY (MIXER) ZB 12-4
LM42A162	LM-42A SHIM FOR FEED SCREW
LM42A163	LM-42A CABLE GLAND
LM42A164	LM-42A CABLE
LM42A165	LM-42A PLUG
LM42A166	LM-42A KEY SWITCH FOR FOOT SWITCH
LM42A167	LM-42A FOOT SWITCH
LM42A168	LM-42A MICROSWITCH FOR FOOT SWITCH SU 1
LM42A169	LM-42A GEARBOX FOR MIXER
LM42A170	LM-42A MIXING SHAFT KEY
LM42A171	LM-42A ENTRY NUT KEY
LM42A172	LM-42A KEY FOR FEEDSCREW
LM42A173	LM-42A TRANSFORMER
LM42A174	LM-42A CASING
LM42A200	LM-42A BEARING TRESTLE COMPL. (INCL PARTS 15-17,19,24,26,140)
LM42A202	LM-42A KEY OLD MODEL
LM42A203	LM-42A MOTOR 11 kW
LM42A204	LM-42A MOTOR FOR MIXER 1,5 kW
LM42A205	LM-42A BELT XPA 1120




(200) = 15, 16, 17, 19, 24, 26, 140

LM-42A  
 LM-130A



LM-42A  
LM-130A



LM-42A  
LM-130A